

## GROUP Q.15. SWITCHBOX (Continued)

SPINDLE, main contact, assembly, consisting of:-	31	RD.3189A	1
Bush, insulating		D.74903	1
Bush, insulating, large		D.74898	1
Contact, front, main		D.74894	1
Contact, rear, main		D.74896	1
Coupling		D.74264	1
Coupling, barrel		D.74897	1
Nut, coupling, retaining		D.74265	1
Ring, securing		D.74276	1
Spindle		D.74895	1
Washer, insulating, large		D.50341	2
Washer, large steel, chamfered		D.74275	1
Washer, plain, thrust, large		RD.3190	1
Washer, insulating		RD.7546	1
SPRING, CAMS	32	RD.3191	2
SPRING, starter button return	33	D.74669	1
STOP, brush	34	D.74932	1
STOP, brush	35	D.74933	1
STOP, brush, parking light	36	D.74295	1
STOP, brush, to starter and ammeter	37	D.74926	1
SWITCH, master, contact maker	38	D.74902	1
TAB, locking, main switch lever	39	D.74266	1
WASHER, spring carbon contact	40	D.74668	1
WASHER, insulating, small, main contact spindle	41	D.1426	2
WASHER, plain, adjacent to spring washer on main contact spindle		K.4404/Z	1
WASHER, plain, finger spindle and spring		K.4402/Z	4
WASHER, plain, 3 BA, ignition switch		K.4446/Z	1
WASHER, plain, studs and terminals		K.4446/Z	11
WASHER, plain, thrust, small, main contact spindle	42	RD.3188	1
WASHER, spring, 7 BA, connection		K.9002/Z	1
WASHER, spring, 5 BA, brush screw, finger spring, lamp screws, starter switch		K.9003/Z	16
WASHER, spring, 3 BA, studs and terminals		K.9005/Z	11
WASHER, spring, 2 BA, main contact spindle		K.9006/Z	1
WASHER, spring, 2 BA, switchbox screw		K.9006/Z	2
WASHER, Thackeray, 3 BA cover studs		K.3902/Z	3
GUARD, switchbox keys		DW.868	1

## GROUP Q.16. SWITCHES SEPARATE.

Comprising:

BASE, stop and reverse light switch assembly, consisting of:-	1	DW.237A	1
Base		DW.237	1
Insert, bracket		D.100456	2
Insert, terminal		D.73732	2

GROUP Q.16. (Continued overleaf)

## GROUP Q16. SWITCHES SEPARATE. (Contd.)

CAP, spring, stop and reverse light switch.	2	DW. 235	1	
CAP, rubber, footswitch.	3	RD. 5153	1	
CLIP, cover, stop and reverse light switch.	4	DB. 410	1	
CLIP, tail light switch cables.	5	RD. 3434	1	*
CONTACT, stop and reverse light switch.	6	DB. 525	2	
COVER, stop and reverse light switch.	7	DB. 408	1	
NUT, roof light switch.	8	RD. 4118	2	VV
NUT, half, 3 BA. stop and reverse light contacts and terminals.	X.24	K. 4305/Z	4	
NUT, half, 3 BA. stop and reverse light switch base.	X.24	K. 4304/Z	2	
PIN, split, .062" dia., stop and reverse light spring cap retaining.	X.31	K. 4602/Z	1	
PLATE, contact stop, stop and reverse light switch.	9	DB. 526	2	
PLUNGER, stop and reverse light switch, assembly consisting of:	10	DW. 234A	1	
Rod, operating.		DW. 234	1	
Support, insulation.		DW. 233	1	
Tube, contact.		DB. 414	1	
SCREW, cheese-head, 2 BA, footswitch retaining.	X.46	K. 1910/Z	2	
SCREW, No.2, luggage boot lamp.	11	RD. 4778	2	W
SPRING, contact, stop and reverse light switch.	12	DB. 417	1	
SWITCH, foot, Lucas No.FS.22.	13	DB.2360	1	
SWITCH, progressive, on/off luggage boot lamp.	14	RD.4062	1	VV
SWITCH, seesaw, luggage boot lamp.	15	RD.3572	1	WW
SWITCH, progressive, on/off tail light.		RD.4062	1	*
SWITCH, door, roof light.	16	RD.3830	4	XX
SWITCH, roof light manual.	17	RD.3282	2	VV
SWITCH, roof light see saw.		RD.3572	2	WW/XX
SWITCH, starter solenoid, See Group Q1.				
WASHER, plain, stop and reverse light switch terminals.	X.85	K. 4447/Z	2	
WASHER, spring, 3 BA. stop and reverse light switch, base and contacts.	X.87	K. 9005/Z	6	
WASHER, spring, 2 BA. footswitch retaining.	X.87	K. 9006/Z	2	

\* Normally fitted to cars for use in Australia.

## GROUP Q17. TRAFFICATOR.

Comprising:

HANDLE, trafficator time switch.	1	RD. 3466	1	
PIECE, distance, time switch.	2	RD. 4560	1	
SCREW, time switch retaining.	3	RD. 4350	2	
SCREW, trafficator fixing.	4	RD. 3954	2	
SWITCH, time, assembly with handle screw.	5	RD. 3107	1	

GROUP Q17. (Continued Overleaf)

## GROUP Q17. TRAFFICATOR. (Contd.)

TRAFFICATOR, Lucas No. SF.34.LH. 54003A  
assembly including:

	6	RD.3211	2
Arm, assembly.		RD.4444	1
Bulb, 12v.		RD.4167	1
Cover.		RD.4445	1
Eyelet.		RD.4448	1
Lead.		RD.4446	1
WASHER, locking trafficator, screw.	7	RD.3953	2
WASHER, spring, time switch screw.	8	RD.3273	2

## GROUP Q18. WIPER WINDSCREEN (Berkshire).

Comprising:

ARM, wiper, assembly.	1	RD.4139	2
BLADE, wiper.	2	RD.4138	2
BOLT, .250" dia. motor mounting.	X.10	K. 209/Z	2
BUSH, rubber, fixing screw.	3	RD.3520	4
BUSH, rubber, fixing screw.		RD.3521	4
CABLE, earthing, with cable eye, KB.5593-4.	4	KB.5568A	1
COLLET, arm to spindle.	5	RD.4159	2
DRIVE, flexible, between gear boxes.	6	RD.3777	1
DRIVE, flexible, motor to gearboxes.	7	RD.3776	1
GEARBOX, Houdaille, RAD.37 with switch knobs.	8	RD.3775	2
GROMMET, rubber, drive cables.	9	RD.3436	1
GROMMET, rubber, wiper spindle.	10	RD.3275	2
MOTOR, Berkshire, with rubber mounting pad and distance pieces, RD.4041.	11	RD.3774	1
NUT, collet operating.	12	RD.4245	2
NUT, half, .250" dia. motor mounting bolt and dashboard, blanking screw.	X.24	K. 4310/Z	2
PACKING, rubber, gearbox mounting.	13	RD.3687	2
PIN, split, .062" dia. gearbox retaining.	X.31	K. 4601/Z	4
SCREW, binding, .250" dia. dashboard, blanking.		CS.30641/Z	1
STOP, rubber, blade retaining.	14	RD.4246	2
STUD, gearbox mounting (fitted in windscreen heater duct).	15	RD.3688	4
WASHER, plain, .250" dia. dashboard blanking.	X.84	KB.3905/Z	2
WASHER, plain, motor mounting bolt.	X.84	KB.3905/Z	2
WASHER, plain, wiper gearbox.	X.85	K. 4404	4
WASHER, rubber, fixing screw.	16	RD.3522	4
WASHER, spring, .250" dia. motor mounting bolt, and dashboard blanking.	X.87	K. 9008/Z	3
WIRE, locking stud.		RD.4328	4

## GROUP Q18A. WIPER, WINDSCREEN (Lucas).

Comprising:

ARM, wiper, or		RD.4139	2
----------------	--	---------	---

GROUP Q18A. (Continued Overleaf)

## GROUP Q18A. WIPER, WINDSCREEN (Lucas), (Contd.)

ARM, wiper.	1	RD.4816	2	
BLADE, or		RD.4138	2	
BLADE.	2	RD.7562	2	
BLOCK, rubber mounting.	3	RD.6222	3	
COLLET, wiper arm (used with RD.4139 arm).		RD.4244	2	
COLLET, wiper arm (used with RD.4816 arm).	4	RD.4819	2	
GROMMET, wiper spindle.	5	RD.4137	2	
GROMMET, cable.	6	RD.4237	1	
MOTOR, spindle boxes and drive assembly including: (R.C).		RD.4140	1	M
Cable and rack assembly with cross head.	7	RD.6227	1	
Clip, cable.	8	RD.6225	1	
Knob.	9	RD.5351	2	
Wheel box assembly with switch.	10	RD.6229	1	
Wheel box assembly less switch.		RD.6330	1	
MOTOR, spindle boxes and drive assembly (R.C) as above, except for cable assembly. (Used with RD.4139 arm).		RD.5443	1	N
MOTOR, spindle boxes and drive assembly (R.C) as above, except for spindle. (Used with RD.4816 arm).	11	RD.5950	1	N
MOTOR, spindle boxes and drive assembly (L.C) as above, except for re-arrangement of spindle boxes and drive. (Used with RD.4139 arm).		RD.4967	1	
MOTOR, spindle boxes and drive assembly (L.C) as above, except for spindle. (Used with RD.4816 arm).		RD.5641	1	
NUT, collet, wiper arm (used with RD.4139 arm).		RD.4245	2	
NUT, collet, wiper arm (used with RD.4816 arm).	12	RD.4820	2	
NUT, 2 BA. spindle box mounting (when fitted).		R.4307/Z	4	
PIECE, distance, spindle boxes (when fitted).	13	RD.4143	4	
PLATE, mounting spindle box, R.H. (when fitted).	14	RD.4239	1	
PLATE, mounting spindle box, L.H. (when fitted).		RD.4240	1	
SCREW, cheese-head, 2 BA. spindle boxes mounting (when fitted).	X.46	K.1907/Z	4	
SCREW, c/sk. head, 2 BA. spindle boxes mounting (when fitted).	X.50	K.2807/Z	4	
STOP, wiper arm.		RD.4246	2	
WASHER, mounting, spindle boxes.	15	RD.4319	4	B
WASHER, plain, 2 BA. mounting spindle boxes.	X.85	K.4404/Z	4	
WASHER, FS. 2 BA. mounting spindle boxes.	X.87	K.9006/Z	4	

## GROUP Q19. WIRING DASHBOARD.

Comprising:

CLIP, 18 mm. bore, PVC tubing, L.H. dash.	1	RD.3043	2	M
CLIP, 14 mm. bore, PVC tubing, R.H. dash.		RD.3042	1	M
CLIP, 18 mm. bore PVC tubing.		RD.3043	3	N
CLIP, Jubilee, loom to connection.		RD.4608	1	

GROUP Q19. (Continued Overleaf)

## GROUP Q19. WIRING DASHBOARD. (Contd.)

CLIP, support sleeving.		RD. 5100	2	N
CLIP, L.H. dashboard conduits.		RD. 3058	3	N
CLIP, L.H. dashboard conduit.	2	RD. 3058	1	N
CLIP, foot switch conduit.	3	RD. 3059	2	M
CLIP, R.H. dash conduit.	4	RD. 3060	1	M
CLIP, R.H. dash conduit.		RD. 4936	1	N
CONDUIT, L.H. side of dashboard.	5	RD. 3062	1	M
CONDUIT, L.H. side of dashboard.		RD. 5105	1	N
CONDUIT, R.H. side of dashboard.	6	RD. 3063	1	M
CONDUIT, R.H. side of dashboard.		RD. 4937	1	N
CONDUIT, horizontal.	7	RD. 4014	1	M
CONDUIT, to foot switch.	8	RD. 3061	1	M
CONNECTION, switchbox loom to dashboard.	9	RD. 3073	1	
ELBOW, conduit, L.H. side of dashboard.	10	RD. 3065	1	M
ELBOW, conduit, L.H. side of dashboard.		RD. 5103	1	N
ELBOW, conduit, R.H. side of dashboard.	11	RD. 3066	1	M
ELBOW, conduit, R.H. side of dashboard.		RD. 5102	1	N
GROMMET, rubber.	12	RD. 3097	1	M
SCREW, cheese-head, 2 BA. conduit clip retaining.	X.46	K. 1904/Z	5	M
SCREW, cheese-head, 2 BA. conduit clip retaining (9 only on coachbuilt cars.)		K. 1904/Z	10	N
SCREW, cheese-head, 2 BA. conduit clip retaining.	X.46	K. 1907/Z	5	M
SCREW, cheese-head, 2 BA. conduit elbow retaining.	X.46	K. 1922/Z	4	
SCREW, cheese-head, 2 BA. conduit elbow L.H.		K. 1922/Z	2	N
SCREW, cheese-head, 2 BA. conduit elbow R.H.	X.46	K. 1928/Z	2	N
SCREW, cheese-head, 2 BA. connection to dash- board retaining.		K. 1904/Z	2	
WASHER, spring, 2 BA. conduit elbow clip and connection retaining screws.	X.87	K. 9006/Z	16	

## GROUP Q20. WIRING, LOW TENSION AND FITTINGS.

Comprising:

BOLT, 2 BA, harness clip (R.C).	X. 9	K. 103/Z	25	O
BOLT, 2 BA, harness clip (R.C).		K. 103/Z	17	P
BOLT, 2 BA, harness clip (R.C).		K. 103/Z	18	Q
BOLT, 2 BA, harness clip (R.C).		K. 103/Z	19	N
BOLT, 2 BA, harness clip (L.C).		K. 103/Z	27	
CABLE, charging plug to connector (Reg 'E').		RD. 5755	1	U
CABLE, charging plug to connector (Dist. Board).		RD. 5756	1	R
CABLE, defroster switch to defroster unit.		RD. 3799	1	R
CABLE, defroster unit to earth.		RD. 3861	1	R
CABLE, distribution board '11' to coil.		RD. 4012	1	M
CABLE, footswitch to distribution board.		RD. 3794	1	R
CABLE, front junction box to horn L.H. & R.H.		RD. 6048	2	
CABLE, horn button, L.H. front junction box to horn relay.		RD. 5168	1	
CABLE, horn relay supply to horn relay coil.		RD. 3810	1	
CABLE, horn relay to L.H. front junction box (horn) (L.C).		RD. 5165	1	

GROUP Q20. (Continued Overleaf).

## GROUP Q20. WIRING, LOW TENSION AND FITTINGS. (Contd.)

CABLE, ignition coil to distributor.	RD. 5683	1	
CABLE, L.H. front junction box to horn relay.	RD. 5164	1	
CABLE, 12-way junction box to wiper motor.	RD. 3807	1	M
CABLE, 12-way junction box to footswitch supply.	RD. 3793	1	M
CABLE, 12-way junction box to solenoid switch 'H'.	RD. 3796	1	M
CABLE, regulator 'E' to earth.	RD. 3795	1	
CABLE, solenoid switch to earth (R.C.).	RD. 3617	1	
CABLE, solenoid, switch to main fuse.	RD. 3789	1	S
CABLE, solenoid, switch to main fuse.	RD. 6007	1	T
CABLE, wiper motor to earth.	RD. 3808	1	M
CLIP, cable luggage boot lamp switch.	RD. 4257	4	
CLIP, cable luggage boot lamp switch.	RD. 6082	3	
CLIP, Trimount spring, L.T. cable to coil retaining.	RD. 3434	1	M
CLIP, harness, 11 mm. (R.C.).	RD. 3041	10	
CLIP, harness, 11 mm. (L.C.).	RD. 3041	17	
CLIP, harness, 14 mm. horn cable (R.C.).	RD. 3042	2	S
CLIP, 11 mm. sleeving reverse light switch (L.C.).	RD. 4746	3	
CLIP, 14 mm. valance plates and cross members.	RD. 3042	7	
CLIP, 7 mm. sleeving heater junction box.	RD. 5161	1	Q
CLIP, 7 mm. sleeving heater junction box.	RD. 5161	2	N
CLIP, 5 mm. sleeving horn cable.	RD. 6082	2	T/N
CLIP, 5 mm. sleeving oil sump unit.	RD. 4004	3	T/N
CLIP, cable oil sump unit.	RD. 4004	2	S
CLIP, cable electric clock cubby box door.	RD. 6082	1	OO/PP
CLIP, 18 mm. sleeving.	RD. 3043	3	
CLIP, 18 mm. sleeving R.H. valance plates.	RD. 3043	3	
CLIP, 18 mm. sleeving main trunk.	RD. 3043	3	
COVER, terminal car heater.	RD. 3106	2	H
GROMMET, rubber (L.C.).	RD. 3209	7	
LOOM, instrument board, assembly. (R.C), consisting of:	RD. 3823	1	R
Cable, demister to heater switch.	RD. 3797	1	
Cable, demister switch to defroster switch.	RD. 3798	1	
Cable, instrument light switch to map light switch.	RD. 3812	1	
Cable, screen wiper switch to fuel gauge.	RD. 3816	1	
Cable, fuel gauge, to fuel oil switch.	RD. 3817	1	
Cable, heater switch to screen wiper switch.	RD. 3862	1	
Cable, switch box '8' to ammeter.	RD. 3844	1	
Cable, earth, light, 4 in 1 instruments.	RD. 4545	1	
Eye, cable (Dowler).	RD. 3690	7	
Eye, cable (Lucas).	RD. 3344	1	
Sleeve, rubber.	RD. 7589	8	
LOOM, instrument board assembly (R.C) as above but RD. 3798 deleted.	RD. 5718	1	V
LOOM, instrument board assembly, (R.C) as above except:	RD. 5009	1	W
Cable switch box '8' to ammeter (replaces RD. 3844).	RD. 6016	1	

GROUP Q20. (Continued Overleaf)

## GROUP Q20. WIRING LOW TENSION AND FITTINGS. (Contd.)

LOOM, instrument board (R.C) assembly as above except:	RD. 7634	1	
Cable, radio to cigar lighter (additional).	RD. 6577	1	
Cable, switchbox '8' ammeter (replaces RD.6016).	RD. 7595	1	
Eye, cable 3 BA. (Lucas).	RD. 3344	2	
Eye, cable (Dowler) (additional).	RD. 3533	1	
Sleeve, rubber.	RD. 7589	10	
LOOM, instrument board to dashboard assembly (R.C) consisting of:	RD. 3822	1	Y
Cable, distribution board to switch box.	RD. 3843	1	
Cable, ammeter to regulator 'A1'.	RD. 3845	1	
Cable, switchbox '2' to regulator 'A1'.	RD. 3846	1	
Cable, switchbox '8' to distribution board '8'.	RD. 3848	1	
Cable, switchbox '11' to distribution board '11'.	RD. 3849	1	
Cable, front cigar lighter to distribution board '8'.	RD. 3851	1	
Cable, demister switch to distribution board '11'.	RD. 3852	1	
Cable, switch box '4' to twelve way junction box.	RD. 3853	1	
Cable, switch box '5' to distribution board '5'.	RD. 3854	1	
Cable switch box '6' to distribution board '6'.	RD. 3855	1	
Cable, instrument board to dash.	RD. 3856	1	
Cable, switch box '10' to 12-way junction box.	RD. 3858	1	
Cable, trafficator switch to distribution board '6'.	RD. 3865	1	
Cable, trafficator switch, L.H. to 12-way junction box.	RD. 3870	1	
Cable, trafficator switch R.H. to 12-way junction box.	RD. 3871	1	
Cable, wiper switch to 12-way junction box.	RD. 3872	1	
Cable, heater switch to 12-way junction box.	RD. 3874	1	
Cable, instrument light switch to distribution board '5'.	RD. 3877	1	
Cable, fuel oil switch to 12-way junction box (petrol tank unit).	RD. 3879	1	
Cable, fuel pipe switch to 12-way junction box (oil sump unit).	RD. 3880	1	
Cable, fuel warning light to 12-way junction box.	RD. 3882	1	
Cable, ignition warning light to regulator 'D'.	RD. 3884	1	
Cable, coachbuilders junction box to distribution board '8'.	RD. 3790	1	
Eye, cable 3 BA. (Lucas).	RD. 3344	8	
Eye, cable, 3 BA. (Dowler).	RD. 3690	16	
Eye, cable, 2 BA. (Dowler).	RD. 3533	1	
Eye, cable, cigar lighter.	RD. 3956	1	
Sleeving, 30 mm.	RD. 3080	1	
Sleeve, rubber, cable eye (R.C).	RD. 7589	25	

GROUP Q20. (Continued Overleaf).

## GROUP Q20. WIRING LOW TENSION AND FITTINGS. (Contd.)

LOOM, instrument board to dash, assembly (R.C) as above except:	RD. 5388	1	Z
Cable, charging plug to regulator 'E' (additional).	RD. 4660	1	
Cable, charging plug to distribution board (additional).	RD. 4661	1	
Eye, cable 3 BA, (Lucas).	RD. 3344	11	
Sleeve, rubber cable eye.	RD. 7589	28	
LOOM, instrument board to dash assembly, (R.C) as above except.	RD. 5143	1	
Cable, fog lamp switch to 12-way junction box (additional).	RD. 4553	1	
Cable, distribution board to fog lamp switch (additional).	RD. 4555	1	
Eye, cable 3 BA. (Dowler).	RD. 3690	17	
Sleeve, rubber.	RD. 7589	29	
LOOM, instrument board to dash (R.C) as above except:	RD. 6027	1	FF
Cable, switchbox (-) to distribution board (-) (replaces RD. 3843).	RD. 6017	1	
Cable, switchbox (2) to regulator A.1 (replaces RD. 3846).	RD. 6018	1	
Cable, switchbox (8) to distribution board '8' (replaces RD. 3848).	RD. 6019	1	
Cable, ammeter to regulator 'A' (replaces RD. 3845).	RD. 6020	1	
Cable, speedo. to coachbuilders junction box (additional).	RD. 4849	1	
LOOM, instrument board to dash (R.C) assembly, as above except:	RD. 5812	1	GG
Cable, demister switch to 12-way junction box (additional).	RD. 5012	1	
Cable, fog lamp switch to 12-way junction box (replaces RD. 4533).	RD. 5014	1	
Cable, fog lamp switch to distribution board '5' (replaces RD. 4555).	RD. 5015	1	
LOOM, instrument board to dash assembly, (R.C) as above except:	RD. 6446	1	HH
Cable, regulator 'E' to charging plug connector (additional).	RD. 5753	1	
Cable, distribution board to charging plug connector (additional).	RD. 5749	1	
Connector, male, charging plug (additional).	RD. 5745	2	
Eye, cable 3 BA. (Lucas).	RD. 3344	9	
Sleeve, rubber.	RD. 7589	27	
Sleeving, 11 mm. charging plug connector (additional).	RD. 5761	1	

GROUP Q20. (Continued overleaf).

## GROUP Q20. WIRING LOW TENSION AND FITTINGS. (Contd.)

## LOOM, instrument board to dash assembly (R.C) (Contd.)

The following are deleted:-

Cable, charging plug to regulator 'B' RD.4660.

Cable, charging plug to distribution board  
RD.4661.

LOOM, instrument board to dash assembly (R.C)  
as above, except:

RD. 5763 1 JJ

Cable, electric clock (additional).

RD. 5721 1

Cable, connector to distribution board  
(additional).

RD. 5717 1

Cover, cable eye, condensor, electric clock  
(additional).

RD. 3106 1

Eye, cable (Dowler).

RD. 3690 20

Eye, cable, electric clock (additional).

RD. 3955 2

Insulator, nipple, electric clock (additional).

RD. 7547 1

Nipple, electric clock (additional).

RD. 7548 1

Sleeve, rubber cable eye.

RD. 7589 28

LOOM, instrument board to dash assembly (R.C),  
as above except:

RD. 7632 1 X

Cable, ammeter to regulator 'A1' (replaces  
RD.6020).

RD. 7594 1

Clip, cable, electric clock, cubby box door  
(additional).

RD. 6082 1

Eye, cable (Dowler).

RD. 3533 2

Sleeve, rubber cable eye.

RD. 7589 29

LOOM, instrument board to dash assembly (L.C)  
consisting of:

RD. 5011 1 M/GG/HH

Cable switchbox '11' to distribution board '11'.

RD. 3849 1

Cable, front cigar lighter to distribution  
board '8'.

RD. 3851 1

Cable, demister switch to distribution board '11'.

RD. 3852 1

Cable, demister switch to 12-way junction box.

RD. 5012 1

Cable, switchbox '4' to 12-way junction box.

RD. 3853 1

Cable, switchbox '5' to distribution board '5'.

RD. 3854 1

Cable, switchbox '6' to distribution board '6'.

RD. 3855 1

Cable, earth, instrument board to dash.

RD. 3856 1

Cable, switchbox '10' to 12-way junction box.

RD. 3858 1

Cable, trafficator switch to distribution board  
'6'.

RD. 3865 1

Cable, trafficator switch L.H. to 12-way  
junction box.

RD. 3870 1

Cable, trafficator switch R.H. to 12-way junction  
box.

RD. 3871 1

Cable, wiper switch to 12-way junction box.

RD. 3872 1

Cable, heater switch to 12-way junction box.

RD. 3874 1

Cable, instrument light switch to distribution  
board '5'.

RD. 3877 1

GROUP Q20. (Continued Overleaf)

## GROUP Q20. WIRING LOW TENSION AND FITTINGS. (Contd.)

## LOOM, instrument board to dash assembly (L.C) (Contd.)

Cable, fuel oil switch to 12-way junction box (petrol tank unit).	RD. 3879	1	
Cable, fuel oil switch to 12-way junction box (oil sump unit).	RD. 3880	1	
Cable, fuel warning light to 12-way junction box.	RD. 3882	1	
Cable, ignition warning light to regulator 'D'.	RD. 3884	1	
Cable, coachbuilder's junction box to distribution board '8'.	RD. 3790	1	
Cable, speedometer warning light to coachbuilder's junction box.	RD. 4849	1	
Cable, switchbox positive to main fuse.	RD. 6017	1	
Cable, switchbox '2' to regulator 'A1'.	RD. 6018	1	
Cable, switchbox '8' to distribution board '8'.	RD. 6019	1	
Cable, ammeter to regulator 'A'.	RD. 6020	1	
Cable, fog lamp to 12-way junction box.	RD. 5014	1	
Cable, fog lamp switch to distribution board '5'.	RD. 5015	1	
Eye, cable 3 BA, (Lucas).	RD. 3344	8	
Eye, cable, cigar lighter (Smiths).	RD. 3956	1	
Eye, cable, 2 BA, (Dowler).	RD. 3533	1	
Eye, cable, 3 BA, (Dowler).	RD. 3690	17	
Sleeve.	RD. 7589	26	
Sleeving, 30 mm. instrument board to dashboard.	RD. 3080	1	
LOOM, instrument board to dash (L.C) as above except:	RD. 7564	1	JJ
Cable, electric clock (additional).	RD. 5716	1	
Cable, condensor to distribution board (additional).	RD. 5717	1	
Clip, cable electric clock, cubby box door (additional).	RD. 6082	1	
Cover, cable eye, condensor clock (additional).	RD. 3106	1	
Eye, cable (Dowler).	RD. 3690	20	
Eye, cable, electric clock (additional).	RD. 3955	2	
Insulator, nipple, electric clock (additional).	RD. 7547	1	
Nipple, electric clock (additional).	RD. 7548	1	
Sleeve, rubber, cable eye.	RD. 7589	27	
LOOM, instrument board to dash (L.C) as above except:	RD. 7633	1	X
Cable, ammeter to regulator 'A1' (replaces RD. 6020).	RD. 7594	1	
Eye, cable, 2 BA, (Dowler).	RD. 3533	2	
LOOM, assembly, rear (R.C).	RD. 3829	1	M
Cable, '5' to tail junction box.	RD. 3873	1	
Cable, distribution board '6' to body junction box companion.	RD. 3819	1	
Cable, distribution board '6' to reverse lamp switch.	RD. 3803	1	
Cable, distribution board '8' to body junction box cigar.	RD. 3792	1	
Cable, distribution board '11' to petrol pumps 'A' and 'B'.	RD. 3802	1	

GROUP Q20. (Continued Overleaf)

## GROUP Q20. WIRING LOW TENSION AND FITTINGS. (Contd.)

## LOOM, assembly, rear (R.C) (Contd.).

Cable, distribution board (-) to body junction box, roof light.	RD. 3815	1	
Cable, 12-way junction box to body junction box, heater.	RD. 3809	1	
Cable, 12-way junction box to body junction box (traff. L.H.).	RD. 3805	1	
Cable, 12-way junction box to body junction box (traff. R.H.).	RD. 3806	1	
Cable, 12-way junction box to fuel tank.	RD. 3881	1	
Cable, 12-way junction box to fuel tank.	RD. 3883	1	
Cable, reverse lamp switch to stop tail lamp switch.	RD. 3804	1	
Cable, reverse lamp switch to tail junction box.	RD. 3866	1	
Cable, stop light switch to tail junction box.	RD. 3867	1	
Cable, body junction box to rear junction box, foot lamp.	RD. 4264	1	
Eye, cable, 2 BA, (Lucas).	RD. 3346	1	
Eye, cable, 2 BA, (Dowler).	RD. 3533	1	
Eye, cable, 3 BA, (Dowler).	RD. 3690	13	
Sleeve, rubber, cable eye.	RD. 7589	15	
Sleeving, 18 mm.	RD. 3087	1	
Sleeving, 11 mm. 2nd cross member to rear junction box.	RD. 3091	1	
Sleeving, 11 mm. petrol tank unit.	RD. 3092	1	
Sleeving, 11 mm. stop and reverse lamp switch body.	RD. 3094	2	
Sleeving, 14 mm. main tank to body junction box.	RD. 3095	1	
LOOM, assy. rear, (R.C) as above except:	RD. 5464	1	KK
Sleeving, 14 mm. main trunk to body junction box. (Replaces RD. 3095).	RD. 5053	1	
LOOM, assy. rear, (R.C) as above except:	RD. 7506	1	LL
Cable, 12-way junction box to petrol tank unit. (Replaces RD. 3881).	RD. 7501	1	
Cable, 12-way junction box to petrol tank unit. (Replaces RD. 3883).	RD. 6250	1	
Sleeving, 14 mm. main tank to 2nd cross member. (Replaces RD. 3090).	RD. 7502	1	
Sleeving, 11 mm. rear junction box to 2nd cross member. (Replaces RD. 3091).	RD. 7503	1	
Sleeving, 2nd cross member petrol tank unit. (Replaces RD. 3092).	RD. 7504	1	
LOOM, assy. rear (L.C) consisting of:	RD. 5061	1	M/KX
Cable, distribution board '8' to body junction box. (Cigar).	RD. 3792	1	

GROUP Q20. (Continued Overleaf)

## GROUP Q20. WIRING LOW TENSION AND FITTINGS. (Contd.)

## LOOM, assembly, rear (L.C.) (Contd.)

Cable, distribution board '11' to petrol pumps A & B.	RD. 3802	1	
Cable, 12-way junction box to body junction box (Trafficator L.H).	RD. 3805	1	
Cable, 12-way junction box to body junction box (Trafficator R.H).	RD. 3806	1	
Cable, 12-way junction box to body junction box (Heater).	RD. 3809	1	
Cable, distribution board (-) to body junction box (Roof Light).	RD. 3815	1	
Cable, body junction box reverse lamp to tail junction box.	RD. 5055	1	
Cable, body junction box, stop lamp to tail junction box.	RD. 5056	1	
Cable, distribution board '5' to tail junction box.	RD. 3873	1	
Cable, 12-way junction box to petrol tank unit.	RD. 3881	1	
Cable, 12-way junction box to petrol tank unit.	RD. 3883	1	
Cable, distribution board '6' to 6-way body junction box (Stop Lamp Switch).	RD. 5028	1	
Eye, cable, 3 BA, (Dowler).	RD. 3690	7	
Eye, cable, 2 BA, (Lucas).	RD. 3346	1	
Eye, cable, 2 BA, (Dowler).	RD. 3533	1	
Sleeve, rubber cable eye.	RD. 7589	9	
Sleeving, 18 mm. main trunk.dash to rear.	RD. 5052	1	
Sleeving, 14 mm. main trunk to 2nd cross-member.	RD. 3090	1	
Sleeving, 11 mm. 2nd cross-member to tail junction box.	RD. 3091	1	
Sleeving, 14 mm. trunk to R.H. body junction box.	RD. 5053	1	
Sleeving, 11 mm. trunk to L.H. body junction box.	RD. 5054	1	
Sleeving, 11 mm. petrol tank unit.	RD. 3092	1	
LOOM, assembly rear (L.C.) as above except:	RD. 7505	1	LL
Cable, 12-way junction box to petrol tank unit (Replaces RD.3881).	RD. 7501	1	
Cable, 12-way junction box to petrol tank unit (Replaces RD.3883).	RD. 6250	1	
Sleeving, 14 mm. main trunk to 2nd cross-member (Replaces RD. 3090).	RD. 7502	1	
Sleeving, 11 mm. 2nd cross-member to rear junction box (Replaces RD.3091).	RD. 7503	1	
Sleeving, petrol tank unit (Replaces RD.3092).	RD. 7504	1	

GROUP Q20. (Continued Overleaf)

## GROUP Q20. WIRING LOW TENSION AND FITTINGS. (Contd.)

LOOM, valance plate, L.H. assembly (R.C), consisting of:	RD. 3825	1	MM
Cable, 12-way junction box to L.H. front junction box (Horn).	RD. 3860	1	
Cable, distribution board to L.H. front junction box (Pass).	RD. 3863	1	
Cable, footswitch to L.H. front junction box (Head).	RD. 3869	1	
Cable, distribution board '5' to L.H. front junction box (Side).	RD. 3876	1	
Eye, cable 3 BA, (Dowler).	RD. 3690	3	
Sleeve, rubber cable eye.	RD. 7589	3	
Sleeving, 14 mm. dash to L.H. valance plate.	RD. 3680	1	
LOOM, valance plate, L.H. assembly (R.C) as above except:	RD. 5064	1	NN
Cable, 12-way junction box to L.H. front junction box (Horn). (Replaces RD. 3860).	RD. 6047	1	
Cable, distribution board L.H. front junction box (Pass). (Replaces RD. 3863).	RD. 6046	1	
Cable, footswitch to L.H. front junction box (Head). (Replaces RD. 3869).	RD. 6044	1	
Cable, distribution board '5' to L.H. front junction box side. (Replaces RD. 3876).	RD. 6043	1	
Sleeving, 14 mm. dash to L.H. valance plate (Replaces RD. 3680).	RD. 6050	1	
LOOM, valance plate, L.H. assembly. (R.C). as above except:	RD. 5144	1	VT
Cable, footswitch to L.H. front junction box (Dip). (Additional).	RD. 4557	1	
The following is omitted: Cable, distribution board to L.H. front junction box (Pass) RD. 6046			
LOOM, valance plate, L.H. assembly (R.C) consisting of:	RD. 5462	1	N
Cable, 12-way junction box to L.H. front junction box (Horn).	RD. 5035	1	
Cable, footswitch to L.H. front junction box (Dip).	RD. 5244	1	
Cable, footswitch to L.H. front junction box (Horn).	RD. 5243	1	
Cable, distributor board '5' to L.H. front junction box (Side).	RD. 5034	1	
Eye, cable, 3 BA. (Dowler).	RD. 3690	3	
Sleeve, rubber cable eyes.	RD. 7589	3	
Sleeving, 14 mm. L.H. valance plate.	RD. 5458	1	

GROUP Q20. (Continued Overleaf)

## GROUP Q20. WIRING LOW TENSION AND FITTINGS. (Contd.)

LOOM, valance plate, L.H. assembly (L.C) consisting of:	RD. 5030	1	
Cable, footswitch to L.H. front junction box (Head).	RD. 5032	1	
Cable, footswitch, to L.H. front junction box (Head).	RD. 5033	1	
Cable, distributor board '5' to L.H. front junction box (Side).	RD. 5034	1	
Cable, 12-way junction box to L.H. front junction box (Horn).	RD. 5035	1	
Cable, distributor board '8' to L.H. front junction box (Horn Relay).	RD. 5036	1	
Cable, L.H. front junction box, horn relay to horn button.	RD. 5166	1	
Eye, cable (Dowler).	RD. 3690	4	
Sleeve, rubber.	RD. 7589	4	
Sleeving, 14 mm. L.H. valance plate.	RD. 5031	1	
Sleeving, 5 mm. L.H. valance plate to steering column.	RD. 5163	1	
LOOM, valance plate, R.H. assembly (L.C).	RD. 5037	1	M/GG/HH
Cable, footswitch to R.H. front junction box (Head) (Pink).	RD. 5039	1	
Cable, footswitch to R.H. front junction box (Head) (White).	RD. 5040	1	
Cable, coachbuilders' junction box to R.H. front junction box (Head).	RD. 4859	1	
Cable, distribution board '5' to R.H. front junction box (Side).	RD. 6042	1	
Cable, 12-way junction box to R.H. front junction box (Horn).	RD. 6039	1	
Cable, main fuse to starter relay.	RD. 5041	1	
Cable, 12-way junction box to R.H. front junction box (Fog).	RD. 5042	1	
Cable, regulator 'F' to dynamo 'F'.	RD. 6079	1	
Cable, regulator 'D' to dynamo 'D'.	RD. 6078	1	
Cable, 12-way junction box to oil sump unit.	RD. 6087	1	
Cable, 12-way junction box to starter relay 'H'.	RD. 5043	1	
Cover, terminal, dynamo 'D'.	RD. 3105	1	
Cover, terminal, dynamo 'F'.	RD. 3106	1	
Eye, cable, 3 BA.	RD. 3344	1	
Eye, cable, starter solenoid switch.	RD. 3103	1	
Eye, cable, 2 BA.	RD. 6081	1	
Eye, cable, .312" dia.	RD. 3345	1	
Eye, cable, 3 BA.	RD. 3690	4	
Sleeve, rubber.	RD. 7589	7	
Sleeving, 18 mm. R.H. valance plate.	RD. 5038	1	
Sleeving, 11 mm. dynamo.	RD. 6086	1	
Sleeving, 5 mm. oil sump unit.	RD. 6084	1	

GROUP Q20. (Continued Overleaf)

## GROUP Q20. WIRING LOW TENSION AND FITTINGS. (Contd.)

LOOM, valance plate R.H. (L.C) assembly, as above except:	RD.6430	1	
Cable, distributor board (-) to starter relay. (Additional).	RD.5521	1	
Cable, 12-way junction box to starter relay 'H'. (Replaces RD.5043).	RD.5523	1	
Eye. cable, 2 BA.	RD.6081	2	
The following parts have been deleted:			
Cable, main fuse to starter relay RD.5041.			
Eye cable to starter solenoid switch RD.3103.			
LOOM, R.H. valance plate assembly, consisting of:	RD.3827	1	MM
Cable, distribution board '8' to horn relay (Supply).	RD.3791	1	
Cable, horn relay, to horn, push button.	RD.3811	1	
Cable, 12-way junction box to oil sump unit.	RD.3818	1	
Cable, horn relay, to front junction box (Horn) R.H.	RD.3850	1	
Cable, 12-way junction box to R.H. front junction box (Horn).	RD.3859	1	
Cable, distribution board, to R.H. front junction box (Pass).	RD.3864	1	
Cable, footswitch to R.H. front junction box (Head).	RD.3868	1	
Cable, distribution board '5' to R.H. front junction box (Side).	RD.3875	1	
Cable, dynamo 'D' to regulator 'D'.	RD.4113	1	
Cable, dynamo 'F' to regulator 'F'.	RD.4115	1	
Cover, terminal, dynamo 'D'.	RD.3105	1	
Eye, cable, 3 BA, (Dowler).	RD.3690	5	
Eye, cable, 4 BA, (Lucas).	RD.3534	1	
Eye, cable, .312" dia. (Lucas).	RD.3345	1	
Eye, cable, 2 BA. (Dowler).	RD.3533	1	
Sleeve, rubber cable eye.	RD.7589	6	
Sleeving, 18 mm. R.H. valance plate.	RD.4000	1	
Sleeving, 14 mm. horn relay to steering column.	RD.4002	1	
Sleeving, 11 mm. horn relay to dynamo.	RD.4108	1	
LOOM, R.H. valance plate assembly, (R.C) as above except:	RD.6053	1	NN
Cable, horn relay to front junction box horn R.H. (Replaces RD.3850).	RD.6045	1	
Cable, 12-way junction box to R.H. front junction box horn (Replaces RD.3859).	RD.6039	1	
Cable, distribution board to R.H. front junction box pass (Replaces RD.3864).	RD.6040	1	
Cable, footswitch to R.H. front junction box head. (Replaces RD.3868).	RD.6041	1	
Cable, distribution board '5' to R.H. front junction box side. (Replaces RD.3875).	RD.6042	1	
Sleeving, 18 mm. R.H. valance plate (Replaces RD.4000).	RD.6049	1	

GROUP Q20. (Continued Overleaf)