

BENTLEY MK. VISECTION BSPARES AND TOOLS

CONTAINING TOOLS AND SPARE
PARTS SUPPLIED WITH EACH CAR.

TOOLS FOR REPAIR DEPOT USE
WILL BE LISTED IN A SEPARATE
SCHEDULE.

KEY TO CHASSIS NUMBERS

Used on	A, B, C, Series	
" "	B-DA All Chassis	
" "	B-DZ 1-191	= F
" "	B-DZ 193 onwards	= G
" "	A, B, C, D, E, F, G, H, J, K, L, M	= H
" "	B-NZ 2-290	
" "	B-NZ 292 onwards	= J
" "	A & B Series	
" "	B-CF 2-234	= K
" "	B-CF 236 onwards	= L

GROUP B1. SPARES AND TOOLS


Comprising

BAR, tommy, .187" dia.	1	KB 6036	1	E
BAR, tommy, .250" dia.		KB 6037	1	E
BAR, tommy, .312" dia.		KB 6038	1	E
BAR, tommy, .406" dia.		RF 4381	1	
BRACE, wheel	2	RF 9084	1	
BULB, headlamp, 12v 48w. (home)	3	RF 4516	1	F
BULB, headlamp, 12v 4.8/4.8w. DC. (home)		RD 5296	1	G
BULB, headlamp, 12v 36w. DC. (All export except U.S.A & Europe)		RD 3970	1	
BULB, headlamp, 12v 36/36w. 3-pin cap (Export Europe)		RD 5330	1	F
BULB, headlamp, 12v 36w. (Export Europe except France)		RD 5329	1	G
BULB, headlamp, 12v 36/36w. (Export France)		RD 5330	1	G
BULB, sidelamp, 12v 3w.	4	RD 5085	1	
BULB, stop-tail 12v 24/6w (when no indexing pin is fitted)		RF 4517	1	
BULB, stop-tail 12v 18/6w (when no indexing pin is fitted)		RD 6602	1	
CAN, oil (as illustrated)	5	RF 3844	1	
CAN, oil (alternative type)		RF 6712	1	
CONDENSER, ignition	6	RD 5881	1	H
CONDENSER, ignition		RD 7774	1	J
GAUGES, feeler	7	RF 6616	1	
GAUGE, tyre pressure	8	RF 5279	1	
GUN, grease	9	RF 9081	1	
HANDLE, Dunlop Jack	10	RF 6018	1	
HANDLE, engine starting (home)	11	RE 18068	1	
HANDLE, engine starting (export bumpers)		RE 18067	1	
HOLDER, valve assembly	12	RF 5214	1	
JACK, bottle type, Dunlop	13	RF 6019	1	L
JACK, Bevelift		RF 3852	1	K
LEVER, drain plug	14	RF 5951	1	
LEVER, tyre, 9 ins. long	15	RF 5595	3	
LEVER, tyre, 18 ins. long		RF 4392	3	E
PAD, Bevelift jack foot		RF 5041	1	K
PLIERS	16	RF 5949	1	
PUMP, tyre, hand type	17	RF 9083	1	
SCREW DRIVER, (Black bakelite handle)	18	RF 5947	1	
SCREW DRIVER, (Hardwood handle)		RF 7227	1	
SPANNER, adjustable	19	RF 6613	1	
SPANNER, box, 5 BA and 3 BA	20	KB 6016	1	E
SPANNER, box, 2 BA and .250" dia., B.S.F.		KB 6017	1	E
SPANNER, box, .312" dia., and .375" dia., B.S.F.		KB 6018	1	E
SPANNER, box, .437" dia., and .500" dia., B.S.F.		RF 5939	1	
SPANNER, box, .750" dia., and .812" dia., B.S.F.		KB 6021	1	E
SPANNER, jaw, 2 BA	21	RF 5908	1	
SPANNER, jaw, .250" dia., B.S.F.		RF 5910	1	
SPANNER, jaw, .312" dia., B.S.F.		RF 5916	1	
SPANNER, jaw, 5 BA and 3 BA	22	RF 5906	1	
SPANNER, jaw, .312" dia., and .375" dia., B.S.F.		RF 5912	1	
SPANNER, jaw, .437" dia., and .500" dia., B.S.F.		RF 5914	1	
SPANNER, ignition, distributor with .020 feeler gauge	23	RF 6612	1	

GROUP B1. (Continued overleaf)

GROUP B1. SPARES AND TOOLS (Continued)

SPANNER, inlet valve tappet	24	RF 5945	1	
SPANNER, exhaust valve tappet	25	RF 8406	1	
SPANNER, wheel disc		RF 3851	1	
SPARKING PLUG, Champion N.8	27	RE 4568	1	
SYRINGE	28	RF 9082	1	
TOOL, tyre valve	29	RF 6614	1	
TOOL, valve spring compressing, exhaust	30	RF 4385	1	E
TOOL, valve spring compressing, inlet	31	RF 4391	1	E



GROUP B1

